

Standard Install



STEP ONE

Confirm that 4" duct is flush to the exterior substrate.



STEP TWO


Add sealant around the perimeter of the backing plate.


STEP THREE

Insert DryerWallVent collar into 4" duct. *If installing a No Collar unit, align opening with duct.


STEP FOUR

To secure to the substrate, install exterior rated fasteners through the inner screw holes.





Backing Plate Install



STEP ONE

STEP FIVE


weeping.

exterior surface.

To expose the fastener holes on the backing plate, remove the two #6 screws on the bottom of the DryerWallVent.

Apply sealant to all sides in contact with final

Tip: Bottom may be unsealed to allow for



STEP TWO


Remove the damper assembly.

STEP THREE Add sealant around the backing plate perimeter.

Specs and Installation

https://dryerwallvent.com/specifications.html


11/24/21, 1:58 PM




Specs and Installation

STEP FOUR

Insert DryerWallVent collar into 4" duct. *If installing a No Collar unit, align opening with duct and skip to Step 5.





STEP FIVE


Install exterior rated fasteners through the outer backing plate holes.

STEP SIX

Insert under the drip edge and secure bottom with the #6 screws.



11/24/21, 1:58 PM



Specs and Installation

STEP SEVEN

For added security, #14 exterior rated screws may be used in the inner screw holes.

STEP EIGHT

Apply sealant to all sides in contact with final exterior surface.

Tip: Bottom may be unsealed to allow for weeping

